

# **mv** Monitor Arm: Quick Setup Guide

## Contents:



**Step 1:** Attach the table clamp firmly to the table.



**Step 2:** Insert the arm extension (optional).



**Step 3 (optional):** If your monitor has a detachable base, remove it according to the monitor user guide.



**Step 4:** Put the monitor on a flat surface (screen facing down) and screw the front piece of the monitor arm to the back of the monitor (thumbscrews enclosed).



**Step 5:** Carefully insert the front piece of the arm into the monitor arm extension (or table clamp if the extension is not used).



**Step 7:** Connect the monitor cable and the power cable to the monitor.



**Step 8:** Squeeze the two lips of the black plastic cover underneath the middle element of the arm and pull the cover away from the base.



**Step 9:** Insert the two cables from the monitor into the cover. Return the cover into its place.



**Step 10:** Secure the cords at the swivel joint with the velcro tape. Leave enough space for the cords to move freely.



**Step 11:** If required, adjust the tension of the height adjustment feature by turning the tension screw in the front piece of the monitor arm with the enclosed Allen wrench (clockwise = tighter).



**Step 12:** Make sure that all screws and connections are tight and secure.

